# PRODUCT INSTRUCTION OF LIVALL PHONE HOLDER

Thanks for using Livall phone holder, to insure a safe and satisfactory operation, please read this product instruction carefully. Please properly keep this instruction for further reference.







## 1. S2 INSTALLATION

remove the original stem and replace it with LIVALL S2 holder.



Original stem



In turns remove the screws and take off the stem

Install S2 on the front fork

Install the four screws on the stem cover

## 2、INSTALLATION OF H2

Remove the two screws on the top of the stem and install Livall H2 phone holder on it.






## 3. ADJUST THE ANGLE OF THE PHONE



Rotate the knob clockwise to loosen the clips.



Pull the top clip upwards, put in your mobile phone and release the top clip to stabilize your phone.



Rotate the knob counterclockwise to fix your phone properly.

## 4. S2 CHARGING THE PHONE

Connect the device to the USB port by a USB cable. During discharging, the remaining power would be displayed.

## 5. CHARGING S2

Connect 6V N the port to a USB charger that has CCC or UL label using Micro USB cable; the charging power would be on display during charging.

## 6. S2 POWER CHECKING

Press Power) to check the remaining power, indicated by

## 7. PRODUCT SPECIFICATIONS

Applicable phone: 4–6 inches
Rotating angle of phone holder: 360°
Vertical turning angle of phone holder: >200°
H2 applies to bikes with M5 screws on the stem and 14–34mm between two screws.
The following parameters apply to S2
S2 Applicable bike: suitable for bikes with the central handlebar diameter being 31.8mm and the diameter of front fork stem being 28.6mm
Battery capacity: 3.7V/5000mAH
Charging port: Micro USB 5V/1A
Charging duration: around 7h
Output port: USB A port, 5V/2A output
Button: power checking
Lighting indicator: four level power indication
Stem length: 120mm
Product size: 180*116*125mm

## 8. PRECAUTIONS

8.1 First use or use after a long time, the mobile battery of the main part would gradually discharge and normally it would take 5 to 6 times of complete charging and discharging for the battery to recover its best performance.
8.2 Please use the 3C or UL charger to charge this product.
8.3 Please refrain from throwing, hitting or shaking this product, or otherwise its internal delicate parts and intact structure would be damaged.
8.4 Please properly keep this product and its relevant accessories in places where children could not easily reach
8.5 During charging, this product would become a little heated, which is totally normal.
8.6 To avoid danger, please refrain from putting this product near any fire or heat sources.
8.7 Please avoid any metal objects from touching the charging and discharging port of the mobile battery, or otherwise it would incur short circuit and damage the main part.
8.8 Performing unauthorized modification or self maintenance would lead to incapacity of your normal use and free maintenance expiration.

# AFTER–SALES SERVICE WARRANTY CARD

After–Sales Information:
Thank you for purchasing LIVALL product, please read the following instructions for better service
1. This product shall be replaced within three months and repaired within one year from the date of purchase.
2. Damages caused by the following reasons are not included in the scope of free warranty:
- Exceeding the specified warranty period;
- Damages caused by unsuitable operation;
- Damages caused by user removing or repairing it by themselves as well as other man–made damages.
3. This warranty card is the important certificate for the warranty service provided to the end user, please keep it well. The card should be taken along with the product to the manufacturer when the maintenance is required.
4.Our company reserves the rights to modification and explanation for above terms and conditions.
Please visit www.livall.com for more information.

User Name: _____
Tel.: _____
ID No.: _____
Home Address: _____
Seller: _____
Purchase Date: _____
Maintenance Record: _____

Note: This form should be completed in real details, otherwise, it would be invalid.